

FLS CARTWheel change Kit

USER GUIDE

50322

1. Carefully lay down the FLS Cart



FEET HEX KEY

X4 X1

2. Remove all 4 wheels using the hex key provided







3. Attach the flat feet to the FLS cart using a flathead screwdriver







*Flathead screwdriver is not included in the kit



Part No: 50322